


## Meter Interface Enclosure

(For Phone AMR and/or Load Pulse output options)



**NOTE:**

- For PULSES ONLY and NO Phone AMR, there will ONLY be an LPOP.
- For Phone AMR ONLY and NO pulses supplied, there will ONLY be a Surge Suppresser & RJ11 jack.